

LEDCHAN610 WALL MOUNTED INSTALLATION INSTRUCTIONS

Extrusion installation:

Tools required:

- Pilot drill matched to appropriately sized pan head screws

1) Carefully mark out on the wall surface a faint centre line or laser-line to position the luminaires in the room.

2) Glue or tape fix is possible.

3) Mitred corners need to be very accurate in order to have tight joints and low light leakage. Task recommends cutting the diffusers mounted in an off-cut of channel and temporarily held with tape for workholding. All cuts should be made slowly on a quality compound drop saw. Back fill the joints with adhesive foil tape to eliminate light leakage from the joint.

4) Read separate Electrical Installation Instructions for subsequent electrical assembly.

Notes:

- Cover diffusers are not UV stabilized and will become brittle in outdoor environments.
- Drivers are remote mounted only

fig 1. channel installed using pan head screws




fig 2. Channel end detail showing potential screw fixing areas

